

PARRING MED ÉN USB DONGLE (skal være fra AK-PMH21OS-FUS-W) og TRÅDLØST TASTATUR

1. Gør musen klar
2. Gør tastaturet klar
3. Tryk FN + ESC på tastatur og begge dele fungerer på samme USB dongle

Instructions and Safety Information



AK-PMH21OS-F series Wireless Hygiene Mouse with Scroll Wheel Sensor

Quick Start:

- 1) Take out the USB receiver dongle
- 2) Insert the supplied batteries as marked inside the battery compartment
- 3) Close the battery cover and tighten the screws
- 4) Connect the dongle to a free USB port at your PC
- 5) Start using the mouse after automatic driver installation has completed

Trådløst tastatur AK-C8100F-FUS/FU1-W-NOR

Installation

1. Insert the 4 batteries as shown on the bottom of the keyboard.
2. Insert the wireless receiver (dongle) into an USB port in the computer.
3. If the keyboard isn't working, please activate the "connect-function" by pressing "Fn" + "Esc" (the "Scroll Lock LED" is now flashing).
4. Wait about 5 seconds (until the LED isn't flashing anymore).
5. The keyboard should now be functional and ready for usage. If that isn't the case please start the installation routine by step 1 again. If the keyboard has still no function please contact our support.

If the product has other defects please contact us.

Please hold these information ready when you contact us:

- Article and serial number of the product
- Name and producer of your PC/notebook or motherboard
- Operating system and if installed version of the service pack

When the batteries are discharged, the status LEDs light up by each keypress. Please replace the batteries as soon as possible.

Function of Fn key:

Key combination	effect	LED status
Fn + Clean on/off	Activates/deactivates the key field. This function is used for cleaning the keyboard, without unplugging it from the PC.	Clean LED flashes
Fn	Shows LED status of Num Lock, Caps Lock, Scroll Lock	On
Fn + Esc	Activates connect-function (look above by installation)	Scroll Lock LED flashes